



Engine

AUX / to Receiver
THR / to Receiver
Telemetrie / to Receiver

Battery
(Option B:
direct connection)

Pro-Interface